

## Low Carbon Multifamily Retrofits

# Post-War 8+ Stories



This playbook summarizes retrofit strategies that maximize occupant comfort and energy savings through a transition from fuel to electricity-based heating, cooling and hot water systems. Aligned with typical capital improvement cycles, the recommendations will prepare buildings for increasingly stringent efficiency and carbon emissions targets through careful phasing of work across all major building components, including upgrades to exterior walls, windows, and ventilation systems.



Additional playbooks are available for these typologies.

## How to use this playbook

### Contents:


- 2: Typology Information
- 3: Model Building Information
- 4: Energy Targets and Phasing Options
- 5: Benefits of Low Carbon Retrofits
- 6-7: Matrix of Efficiency Strategies
- 8: Envelope Strategies
- 9: Ventilation Strategies
- 10: Heating: Cooling Strategies
- 11: Domestic Hot Water/Plug Load Strategies
- 12: Additional Resources

This playbook summarizes those retrofit strategies across all major building systems and components that will maximize occupant comfort and energy savings through a transition from fuel to electricity-based heating, cooling and hot water systems. For clarity of analysis, the playbook assumes an ideal phasing of strategies (page 4) but it is presumed the order of work will be based on the individual needs of the building in question, includ-

ing end of system life, capital planning, and regulatory pressures. The playbook describes the primary benefits of a low carbon retrofit with details on the major system upgrades needed to access those benefits.

## Post-War Mid to High Rise

These buildings are typically between 8 and 25 floors in height and can be found in virtually every context—from lot line buildings like the one shown on the right, to free standing buildings on campuses like the building studied here (page 3). Many buildings of this type include mixed uses at the ground floor, such as retail (grocery stores, pharmacies, etc.) and commercial offices (Doctor’s offices, etc.). Basic tenant amenities are common, such as laundry, gym, and storage.



The height and layout of buildings in this typology vary considerably with both simple towers (page 3) and podium-tower arrangements (above) common, both corner and mid-block.

### Typical ownership challenges

- Owners typically have limited access to capital
- Vacancy is very low (hampering retrofit efforts)
- Tenants are typically responsible for cooling costs (complicating electrification of those systems)
- In buildings with multiple uses (grocery stores, etc.) disaggregating energy use of retail tenants can be difficult if not metered, and typical leases do not envision legislation like Local Law 97

ELEMENTS	DESCRIPTION	TYPICAL ISSUES
Exterior walls	Typically simple load bearing masonry with punched window openings.	<ul style="list-style-type: none"> <li>- Often no insulation</li> <li>- Major thermal bridges at perimeter beams, balconies, and parapets</li> <li>- High maintenance costs</li> </ul>
Windows	Aluminum, double hung frames (no thermal break), single glazing or weak double glazing common.	<ul style="list-style-type: none"> <li>- Little thermal resistance</li> <li>- High air leakage</li> <li>- Major comfort issues</li> <li>- Condensation risk</li> <li>- Absorb significant solar heat</li> </ul>
Heating	Commonly two-pipe steam systems served by oil or gas fired boiler.	<ul style="list-style-type: none"> <li>- Limited control</li> <li>- Overheating common</li> <li>- High short-term maintenance costs</li> </ul>
Cooling	Window AC units, sporadically deployed.	<ul style="list-style-type: none"> <li>- Increases whole building U-value</li> <li>- Creates drafty conditions</li> <li>- Major thermal bridge</li> <li>- Noisy, inefficient</li> <li>- Winter removal very rare</li> </ul>
Domestic Hot Water	Heat exchange at steam boiler with constant recirculation loop.	<ul style="list-style-type: none"> <li>- Requires running steam boiler in shoulder and cooling seasons</li> </ul>
Ventilation	Exhaust only at kitchens and bathrooms; corridors may have exhaust or supply.	<ul style="list-style-type: none"> <li>- No direct fresh air introduction</li> <li>- System is not balanced, drives infiltration from exterior and adjacent units</li> </ul>

# Actual Building Information

The building selected for study is a 15-story, market-rate residential building on a small campus of nearly identical buildings in Brooklyn, New York. Constructed in 1950, the building has masonry exterior walls enclosing 163 apartments across 123,000 gross square feet.

The tower is typical of a large swath of buildings in New York City (as well as many other regions) and has many of the most common challenges that will be encountered by anyone looking to perform a deep retrofit of an occupied multifamily building. The owner of the property generously made drawings and other information about the building available but wished to remain unidentified in the report.

## Utility Costs


Typically, the building owner pays for the utility costs of heating and hot water fuels, gas cooking and common area laundry, as well as electricity costs for all common area functions, including lighting, pumps, fans, and elevators. Tenant utility bills cover only electricity for apartment lighting, appliances, and cooling – which typically includes window AC or Through Wall AC units. Heating and hot water boilers are typically dual fuel (oil or gas).



Like many buildings of this era and type, the window to wall ratio is low, in this case 21%. Photo credit: Steven Winter Associates

## Energy Use Analysis

Heating is by far the dominant energy end use and, therefore, retrofit measures that directly reduce heating demand—such as envelope improvements—are essential to realizing a low carbon future and avoiding penalties like those included in Local Law 97.



## NYC Local Law 97 Carbon Limits



Incremental retrofit measures may bring total building carbon emissions into compliance with the Local Law 97 limits that begin in 2024, but a much more aggressive low carbon retrofit will be required to avoid the financial penalties associated with the 2030 limits.

# Targets & Phasing

To meet the demands of a low carbon future we recommend that buildings pursue the Recommended Targets in the following pages and develop long term retrofit plans to coordinate the phasing and interaction of these measures over time. For more detailed retrofit planning we recommend projects use a building performance standard like EnerPHit, the Passive House standard for retrofits, as a benchmark to evaluate the total impact of various measures once enacted.

## Local Regulatory Context


New York City has passed Local Law 97 which limits carbon emissions in large buildings. The first reporting period is 2024, with requirements becoming more stringent in 2030 and again in 2035. A low carbon retrofit such as recommended here puts a building in the best possible position to avoid financial penalties under Local Law 97.

## Retrofit Phasing

The phasing order shown below is one of many optional pathways available. While implementing envelope measures early maximizes energy efficiency long term, many other factors may determine which measures should be completed in which order—including end of life equipment replacement, tenant disruption and access to capital.

 <p><b>lighting &amp; loads</b></p> <p>Lighting, appliance and plug load efficiency measures can be done at anytime. <b>See page 11</b></p>	 <p><b>envelope</b></p> <p>It is ideal to complete envelope measures early in the process to reduce heating &amp; cooling demand. <b>See page 8</b></p>	 <p><b>ventilation</b></p> <p>Ventilation upgrades should follow airtightness and other envelope improvements as soon as feasible. <b>See page 9</b></p>	 <p><b>heating</b></p> <p>Full electrification of systems typically includes combining heating &amp; cooling into a single heat-pump based system. <b>See page 10</b></p>	 <p><b>cooling</b></p> <p>When existing cooling is window units, upgrades must be carefully coordinated with window replacement. <b>See page 10</b></p>	 <p><b>hot water</b></p> <p>The technology for fully electrifying large-scale hot water systems is not yet readily available in this market; however, there are options for meaningful partial electrification. <b>See page 11</b></p>
--	--	---	---	--	---

## Energy & Cost Reductions by Phase



Because the building envelope plays such a critical role in heating demand and overall comfort, additional wall and roof insulation, improvements to airtightness, and the introduction of high performance windows have the greatest impact on energy use, utility cost, and carbon emission reductions.

## Benefits

Most buildings are upgraded reactively, in response to a system failure or tenant turnover, and focus only on like-for-like equipment replacement. This piecemeal approach leaves significant energy and cost savings on the table, rarely improves the comfort or health of occupant, and is unlikely to align with increasingly stringent efficiency and carbon regulations. Developing a long term retrofit plan, with each phase based on the Recommended Targets listed here, can ensure that measures work in concert to produce spaces that are more comfortable, healthier, and significantly less expensive to maintain and operate.

### Annual Utility Savings



### Health

Upgrading the building envelope and ventilation systems radically improves interior air quality.

Air infiltration through leaky exterior walls and condensation at thermal bridges to the outside are among the primary vectors for poor indoor air quality. The former can be the source of moisture and myriad pollutants while the latter is the foundation of interior mold growth. In a low carbon retrofit improved airtightness and reduced thermal bridging work together with a balanced, highly filtered ventilation system to provide ample fresh air while reducing pollutants, resulting in a far healthier building interior.


### Operating Cost Savings

**Utility cost reductions:** A low carbon retrofit dramatically reduces utility bills through more efficient systems and reduction in demand for heating and cooling systems.


**Facade inspection savings:** Many buildings of this era spend considerable sums on inspection and repair of their aging facades. (In NYC this work is often in service of the Local Law 11 Facade Inspection Safety Program, required every 5 years.) When facade repairs are necessary, costs can range from \$2,500-\$6,500 per apartment, depending on site-specific conditions. Properly designed recladding systems should not require significant maintenance for decades.

**Gas System inspection savings:** In NYC Local Law 152 mandates extensive inspections of gas systems every four years. Inspection costs can range from \$1,000-\$10,000 depending on building size, but if gas leaks are identified, repairs can cost from \$3,000-\$20,000 per unit depending on the severity of the leaks. Buildings that fully decarbonize through switching their gas-based systems like heating, hot water and cooking to electricity-based systems will avoid the considerable costs associated with these inspections and any subsequent repairs.

#### thermal comfort - existing



#### thermal comfort - post retrofit



Insulating the exterior and installing high-performance windows ensures that the inside surface temperature of the exterior walls remains warmer throughout winter and, most importantly, closer to the interior air temperature. Research indicates that comfort is significantly compromised when this difference is greater than 7 degrees F. We estimate the existing building suffers from a difference nearly 3x this figure. Graphic credit: Building Energy Exchange

### Thermal Comfort

Far more comfortable interiors are one of the primary advantages of pursuing a holistic low carbon retrofit.

The difference between air temperature and the surface temperature of exterior walls and windows is a major driver of interior comfort. The diagram above outlines this relationship under the existing building conditions (left) and the conditions once envelope and ventilation improvements are complete (right).

# Post-war Mid & High Rise Efficiency Package

The options for improvement listed here will maximize occupant comfort and energy savings through a transition from fuel to electricity-based heating, cooling and hot water systems. Aligned with typical capital improvement cycles, these strategies will prepare buildings for increasingly stringent efficiency and carbon emissions targets.

	Retrofit Strategies	Benefits				Costs
		Energy Savings	Comfort	Health/IAQ	Maintenance	
 envelope	<b>ROOF</b>					
	→ Insulate Roof	★★	★	★	LOW	\$
	<b>EXTERIOR WALL</b>					
	→ Add Interior insulation	★★	★★★★	★	LOW	\$\$\$
	→ Add Exterior Insulation	★★★★★	★★★★★	★★★★	LOW	\$\$\$\$
	<b>WINDOWS</b>					
	→ Replace Existing Windows with High Performance Windows	★★★★	★★★★★	★★★★	LOW	\$\$\$\$\$
	<b>Air Tightness</b>					
	→ Ensure Air Sealing as part of Exterior Wall & Window Upgrades	★★★★	★★★★	★★★★	LOW	\$\$
 heating	→ Building-Wide VRF System	★★★★★	★★★★★	★★★★	HIGH	\$\$\$\$\$
	 cooling	→ Building-Wide Hydronic Loop with Hybrid ACs	★★★★	★★★★	★★★★	HIGH
 ventilation		→ Centralized Energy Recovery Ventilation System	★★	★★	★★★★★	MEDIUM
	 hot water	→ Air to Water Heat Pump Water Heaters	★★★★	★	★★	MEDIUM
→ Water to Water Heat Pump Water Heaters		★★★★	★	★★	MEDIUM	\$\$\$\$
 lighting & loads	<b>LIGHTING</b>					
	→ High Efficiency Common Area Lighting	★★	★★	★	LOW	\$
	<b>PLUG LOAD</b>					
	→ High Efficiency Appliances and Smart Systems	★★	★★	★★	LOW	\$\$
 solar	<b>PHOTOVOLTAIC</b>					
	→ Install Solar PV Array	★	★	★	LOW	\$

	Retrofit Strategies	Touchpoints			Impacts	
		Anytime	Refi/Major	Tenant Turnover	Tenant Disruption	Appearance Impact
 envelope	<b>ROOF</b>					
	→ Insulate Roof	✓	✓		LOW	LOW
	<b>EXTERIOR WALL</b>					
	→ Add Interior insulation		✓	✓	HIGH	LOW
	→ Add Exterior Insulation	✓	✓		LOW	HIGH
	<b>WINDOWS</b>					
	→ Replace Existing Windows with High Performance Windows	✓	✓	✓	MEDIUM	MEDIUM
	<b>Air Tightness</b>					
	→ Ensure Air Sealing as part of Exterior Wall & Window Upgrades	✓	✓	✓	MEDIUM	MEDIUM
 heating	→ Building-Wide VRF System	✓	✓		HIGH	LOW
	 cooling	→ Building-Wide Hydronic Loop with Hybrid ACs	✓	✓		HIGH
 ventilation		→ Centralized Energy Recovery Ventilation System	✓	✓		HIGH
	 hot water	→ Air to Water Heat Pump Water Heaters	✓	✓		LOW
→ Water to Water Heat Pump Water Heaters		✓	✓		LOW	LOW
 lighting & loads	<b>LIGHTING</b>					
	→ High Efficiency Common Area Lighting	✓	✓		LOW	LOW
	<b>PLUG LOAD</b>					
	→ High Efficiency Appliances and Smart Systems	✓	✓	✓	MEDIUM	LOW
 solar	<b>PHOTOVOLTAIC</b>					
	→ Install Solar PV Array	✓	✓		LOW	LOW



# Envelope Upgrades

A high-performing envelope constitutes the foundation of a low carbon retrofit, with significant emphasis on airtightness, the right amount of insulation, and high-performance windows and doors to dramatically improve comfort and reduce heating and cooling demand.

## Airtightness

Whole building airtightness positively impacts energy use and interior air quality while enabling highly efficient ventilation.

Proper airtightness involves each step of an envelope retrofit. From the correct selection and installation of windows and doors to the creation of an air barrier within the wall assembly (often the adhesive within an EIFS system or a dedicated air barrier within a rainscreen system). Remedial measures should also be implemented to improve airtightness of shafts, fire stairs, bulkheads, and duct risers.

## Insulation

Insulation is the primary method of separating the interior environment from the exterior and is especially critical for retrofits of buildings with no insulation in their existing wall assembly.

Interior applications of insulation are possible, but not when units are occupied. Further, interior insulation applications alone are not optimal for retrofits seeking high R-values, durability, and occupant comfort. Continuous exterior insulation systems are preferred. The primary exterior insulation applications are EIFS or rainscreens with continuous insulation boards. EIFS is likely to be the most cost-effective option.


## Windows

Few elements impact the quality of the interior environment as much as high performance windows.


Low carbon retrofits require careful selection of high-performance windows to ensure interior comfort and optimize heating and cooling demand. To maximize comfort and reduce the potential for condensation, triple-glazing is often recommended. Passive House certified windows are typically preferred as they meet stringent standards for airtightness and thermal bridging. Awning, tilt-turn, and casement style windows are preferred over more traditional double-hung or sliding windows.



**Existing Window:** Although the frames of the proposed Passive House windows are larger than the existing, because the retrofit would allow for the elimination of window AC units the daylight area of the windows are effectively increased by about 15%. Photo credit: Building Energy Exchange



**Proposed Window:** Passive House certified windows benefit from generous thermal breaks within the frame, typically include triple glazing, and, perhaps most importantly, include gasketing and hardware that ensure airtightness. Photo credit: Shuco



## RECOMMENDED TARGETS

- **Roof Insulation:** *Minimum of R-30, or local code minimum.*
- **Add Interior insulation :** *Minimum of R-20*
- **Add Exterior Insulation :** *Minimum of R-10*
- **Replace Existing Windows with High Performance Windows:** *Recommended U value = 0.167 Btu/hr.ft².F*
- **Reduce Air Leakage:** *Recommended airtightness = 1.0 ACH*
- **Whole Building U-value:** *0.093 Btu/hr.ft².F*

## Whole Envelope Performance

Building owners pursuing a low carbon retrofit can follow the Recommended Targets for individual element listed here, or they can model the performance of the entire exterior assembly to meet a whole building U-value. With this latter method an owner can trade higher performance in one area, say additional insulation, with slightly lower specifications in another area, such as windows, while remaining confident of meeting their whole building carbon emissions goals.

## Special Considerations

Any plan to add insulation to the exterior of a building must be carefully coordinated with any zoning or lot line restrictions, as well as any potential oversight by local authorities such as historic preservation ordinances.

If considering exterior refrigerant piping for heating and cooling systems both the phasing and layout of the piping must be carefully coordinated with any recladding systems.

# Ventilation


A properly implemented low carbon retrofit requires balanced ventilation that delivers properly filtered supply air directly to habitable spaces, while stale air is removed from kitchens, baths and laundries.

Balanced ventilation works in tandem with an airtight envelope to ensure the system draws little air via infiltration from the exterior or from adjacent apartments. In addition, an energy recovery ventilation (ERV) system captures heat that would otherwise be exhausted to the outdoors and uses it to temper the incoming outside air (without transferring pollutants or odors), thereby reducing energy use.

**RECOMMENDED TARGETS**

- Centralized Energy Recovery Ventilation (ERV) System
- Sensible Heat Factor: 80%
- Max Fan Power: 0.76 W/cfm

## Floor Plan: Centralized Ventilation



In the proposed scenario the existing ventilation shafts are repurposed, converting the system from exhaust-only to balanced. Rooftop ERV units serve the new supply risers, and transfer grilles allow the refurbished exhaust lines to extract from each room.

## Ventilation

Ventilation systems should serve every unit and typically have exhaust grills in each kitchen and bath and supply grills at each living area and bedroom. Depending on the system chosen, ERVs can incorporate the ability to control humidity as well as a method to boost supplied air temperature.

**Centralized Ventilation:** Typically, existing ventilation shafts are repurposed and the system converted from exhaust only to balanced (see diagram this page). This arrangement is dependent on sufficient existing shaft area, but results in the fewest number of ventilators, preserving valuable floor area and easing maintenance. Official approval by DOB may be required for the proposed ventilation scheme.

**Decentralized ventilation:** Individual ERVs are provided for each apartment, usually requiring two penetrations through the exterior or wall per apartment. Exterior units may be hung near the ceiling or exterior wall, or potentially on balconies if available.

**Semi-decentralized ventilation:** A single ERV services all the apartments on one floor. Advantages include ease of access for maintenance and elimination of problems that can result from

stack effect in the building; however, the primary disadvantage is the need for a large mechanical space on every floor.

## Special Considerations

**Phasing:** Airtightness and ventilation are directly connected. Older exhaust-only ventilation systems rely on leaky exteriors and gaps between units to draw air out of the building. If the airtightness of a building has been dramatically improved, existing ventilation systems must be carefully analyzed to avoid unhygienic or inefficient conditions.

**Optional Schemes:** Internal investigation will be required to determine optimal ventilation arrangement for each building. For the subject building, decentralized systems are also an option but require multiple penetrations in the exterior wall and complicated maintenance by increasing the number of filters and units to be monitored. Maintenance is often a concern with decentralized systems because the filters in each ERV need to be replaced or cleaned at least twice a year.

# Heating & Cooling Upgrades




Once improvements to the envelope are complete, heating and cooling demand is dramatically reduced.

VRF systems offer significant improvements over existing heating and cooling systems although the refrigerants used to come with a risk of leakage and regulatory phase outs. Maximum refrigerant quantity restrictions often require the use of several smaller VRF systems in a large building. Mini-split heat pump units have less associated refrigerant risk, but often are not a good fit for buildings over 7 stories due to limitations on vertical refrigerant line lengths. Where ground-level space may be limited, buildings above 7 stories utilizing mini-splits will require intermediate locations for the outdoor units.



Although a high performance envelope does not reduce the cooling demand nearly as much as the dramatic reductions in heating demand, reduction in cooling demand by 20-30% remains extremely important as that reduction will occur during periods of peak demand for electricity—periods when utility costs and carbon penalties are likely to be highest in the future.

## Centralized VRF: Risers on the Exterior



The preferred VRF option in this particular building limits interior construction by placing the new refrigerant lines on the outside of the existing masonry walls and directly accessing the new cassettes over each window. Floor standing interior units are also an option.



Similar to "mini-split" systems, VRF systems utilize interior units to deliver heating and cooling. A unit similar to the one shown here would sit above the window in each major room, replacing the steam radiators and window AC units.

### Special Considerations

Most low carbon retrofits result in combining the heating and cooling systems, originally separate, into a single system. This work will typically require electrical upgrades to power the new systems. The timing of this change requires careful consideration and in most cases impacts the responsibility for paying the relevant utility costs. The layout options should be coordinated with ventilation system layouts as well.

### RECOMMENDED TARGETS

- **Building-Wide VRF System:**  
*Cold climate system:*  
 Min. efficiency: → Heating: 3.3 COP @ 47°F  
 → Cooling: 4.4 COP
- **Building-Wide Hydronic Loop + Hybrid ACs: Fed by AWHP or GSHPs:**  
*AWHP - Cold climate system:*  
 Min. efficiency: → Heating: 2.3 COP  
 → Cooling: 2.2 COP

## Heating & Cooling Options

### Building-wide VRF System

Providing both heating and cooling through a building-wide VRF system is among the most effective means of tempering interior conditions efficiently. Common layout options for VRF systems include:

- **Exterior Risers:** Placing refrigerant lines on the exterior minimizes interior disruption but requires some form of recladding.
- **New Interior Chase:** Provide a new vertical chase in a central location for refrigerant risers. Supply lines typically run in corridors and cassettes typically located near unit entrance, often recessed in the entrance ceiling.
- **Replace Steam Risers:** In some cases refrigerant risers can be run in the same location as removed steam risers, though this entails significant disruption in every major room of every unit.

### Low-Temperature Hydronic Loop Served by Heat Pumps

Install a building wide low-temperature hydronic distribution system (or convert an existing steam or hydronic distribution system) with Hybrid Water-Cooled Air Conditioners (HWCACs). Heat injection or rejection to / from the hydronic loop can be served by either rooftop air-to-water heat pumps (AWHP) or ground-source heat pumps (GSHPs). GSHPs are not often feasible within New York City limits and are highly dependent on site-specific geological conditions.

# Domestic Hot Water



To realize the full benefits of a green grid, and to avoid penalties associated with stringent carbon reduction requirements, domestic hot water systems should transition from fossil fuel based systems to electricity based systems. Currently, heat pump hot water systems are limited in size and application for large buildings. Today buildings should consider offsetting a portion of its DHW usage with heat pumps, while still retaining its existing fuel-based system to serve the remaining load.

## Domestic Hot Water electrification system options:

### Air-to-water heat pumps (AWHP) for buildings with VRF heating/cooling

- If VRF system is used for heating/cooling, install an air-to-water heat pump (AWHP) plant outside, either on the roof or at grade, and connect to storage tanks in the basement or other service space.
- Equipment options: As there are a limited number of products that can produce sufficient hot water on the coldest days, the system will need to work in conjunction with a fossil fuel based system or a second "boost" stage, which could be a water-to-water heat pump or a direct electric heater.

### Water-to-water heat pumps (WWHP) for buildings with hydronic heating/cooling

- If hydronic system is used for heating/cooling, install a water-to-water heat pump (WWHP) and storage tank for DHW in the basement or other service space. WWHPs pull heat from the hydronic loop for DHW, providing beneficial cooling in the warm season.
- Equipment options: Unlike AWHPs which require outdoor placement, WWHPs can be installed indoors. Acceptable for multifamily buildings of less than 60 units.



**RECOMMENDED TARGETS**

- Air to Water Heat Pump: *Min. COP: >2.2*
- Water to Water Heat Pump: *Min. COP: >3.1*

**Preparing now for future DHW electrification:**

- Install a small heat pump plant to offset a portion (~30%) of the DHW load now. This will save carbon and give the owner/operator a chance to become familiar with the technology while leaving the fuel-fired plant in place.
- Leave spare electric capacity and breakers so additional equipment and controls can be added in the future without significant electrical work.
- Leave valved off and capped piping to allow for easier heat pump connections in the future.

# Lighting/Plugs/Cooking

Efficiency upgrades to lighting, appliances and equipment can occur at virtually any time and are a good place to begin if new to energy conservation. Switching cooking appliances from gas to electricity (induction) is required to reach full decarbonization and to ensure the health and well being of occupants.

## Lighting and plug load recommendation

- Use LEDs in all hard-wired fixtures and lamps.
- Use ENERGY STAR® appliances, including refrigerators, dishwashers, and laundry equipment.
- Install occupancy sensors, daylighting sensors, and timers where appropriate and allowed (all common areas, fire stairs in some jurisdictions).
- Use smart plugs to reduce equipment loads when the spaces are unoccupied and/or install systems that allow remote operation.



**MINIMAL THRESHOLD**

- High Efficiency Common Area: *50% Reduction in W/SF*
- High Efficiency Appliances and Smart Systems: *55% Reduction in plug loads*

## Induction Cooking

Gas stovetops are a significant contributor to air quality problems in residences and often the final barrier for buildings that wish to fully decarbonize their systems. Induction cooking appliances are available at reasonable costs and should be a focus of anyone looking to improve the overall performance of their building.

Electric stoves and cooktops also reduce the risk of gas leaks and fire, as well as carbon monoxide poisoning.

**BEEx: the building energy exchange connects New York City real estate and design communities to energy and lighting efficiency solutions through exhibitions, education, technology demonstrations, and research. We identify opportunities, navigate barriers to adoption, broker relationships, and showcase best practices online and at our resource center in Manhattan.**

## Resources

Other Playbooks in Series :

- Post-War 8+ Stories  
<https://be-exchange.org/report/lowcarbonmultifamily-postwar-high>
- Pre-War 4-7 Stories  
<https://be-exchange.org/report/lowcarbonmultifamily-prewar-low>
- Post-War 4-7 Stories  
<https://be-exchange.org/report/lowcarbonmultifamily-postwar-low>
- Post 1980 Mid High 8+ Stories  
<https://be-exchange.org/report/lowcarbonmultifamily-post80-highoc>

## BEE X Tech Primers

The following primers directly relevant to this typology are listed below and found here: [be-exchange.org/tech-primers](https://be-exchange.org/tech-primers)

- VRF Systems
- Energy Recovery Ventilators
- Roof Insulation
- Wall Insulation
- High Performance Ventilators
- DHW: Air to Water Heat Pumps
- DHW: Point of Use
- LED Lighting Retrofits
- Plug Loads and Tenant Energy Use Reduction

A more detailed deep retrofit study of this building is available here: <https://be-exchange.org/report/pursuing-passive/>

## Contributors



**NYSERDA**



**Steven Winter Associates, Inc.**  
Improving the Built Environment Since 1972

### Disclaimer

While every effort has been made to contain correct information, neither Building Energy Exchange nor the authors or project advisors makes any warranty, express or implied, or assumes any legal responsibility for the accuracy, completeness, or usefulness of any

information, apparatus, product, or process disclosed, or represents that its use would not infringe privately owned rights. None of the parties involved in the funding or the creation of this study assume any liability or responsibility to the user or any third party for the

accuracy, completeness, or use or reliance on any information contained in the report, or for any injuries, losses or damages arising from such use or reliance.